

INSTALLING COMMO LINES		
STEP	ACTION	✓
1	Test field wire on reel: attach telephone sets to ends; if commo check clear, install wire.	
2	Installing field wire: tie to fixed object to start & end (allow slack); tie several places at ground level	
3	Attach wire tags at road crossings, telephones & test stations, both sides of buried or aerial crossings, locations with several lines.	
4	Test wire line after buried or aerial crossings, before & after splicing new reel, before connecting line to switchboard.	