

## **CROSSING OBJECTS WITH COMMO LINES**

<b>STEP</b>	<b>ACTION</b>	<b>✓</b>
1	<b>Culvert:</b> Attach wire tag on each side of road, pass wire thru culvert, add protective tape at ends of culvert.	
2	<b>Aerial crossings:</b> Clear roads by at least 7m, using trees or poles to raise wire. Use lance poles if needed.	
3	<b>Buried crossings:</b> Dig 6-12" deep trench extending beyond each side of road, lay wire loosely, tag, backfill.	
4	<b>Railroad crossing:</b> Cut enough wire to reach across tracks, pull under tracks & secure with stakes along crossties. Splice to wire reel; bury exposed wire.	